

## INSTALLATION INSTRUCTIONS TANFOGLIO NEW LIMITED CUSTOM

- 1. Use always ONE of the DPM SPRING PLUGS when you use the DPM Recoil Reduction System.
- 2. Before you install the DPM Rod Insert one of the DPM SPRING PLUGS in the slide (Fig.1).
- 3. Finally choose one of the DPM Springs and insert the DPM Recoil Rod in the slide (Fig. 2).







Please read the POWER COMBINATIONS TABLE for all the possible combinations given from the three (3) DPM SPRING PLUGS and the three (3) SPRINGS in cooperation with the DPM RECOIL ROD.

DPM RECOIL SYSTEM - POWER COMBINATIONS TABLE						
TANFOGLIO			Power Slide Battery		Power Slide Full Open Position	
			( <b>kgf</b> ) Kilogram	( <b>lbs</b> ) Pound	( <b>kgf</b> ) Kilogram	(lbs) Pound
A/A	SPRING	SPRING PLUG	Force	Force	Force	Force
1	S-1	P-1	2	4.5	6	13
2	S-1	P-2	2.5	5.5	8	17.5
3	S-1	P-3	3	6.5	10	22
4	S-2	P-1	2	4.5	6	13
5	S-2	P-2	2.5	5.5	8	17.5
6	S-2	P-3	3	6.5	10	22
7	S-3	P-1	2	4.5	6	13
8	S-3	P-2	2.5	5.5	8	17.5
9	S-3	P-3	3	6.5	10	22