


DPM RECOIL SYSTEM

SIG SAUER P320 X-COMPACT & RXP

INSTALLATION INSTRUCTIONS

The DPM Recoil Reduction System includes the Recoil rod, one spring plug and three different in length External Springs. (Fig. 1)

Fig. 1




1. **ATTENTION:** Always install the open coil of the External Springs on the recoil rod flange. (Fig. 2)




Fig. 2

2. **ATTENTION:** Always install the recoil rod base vertically to the barrel correct position. If you place the rod base horizontally, the pistol can't function (Fig. 3, 4)

3. Ensure that the DPM system is placed in the correct way, reassemble the slide on the frame and rack the slide several times to ensure that the DPM Recoil system functions unrestricted.



4. **ATTENTION:** Always use the Spring Plug when the DPM Recoil System is equipped at the pistol. (Fig. 5)



For any questions about the installation or operating instructions:
service@dpmssystems.com | www.dpmssystems.com